

AIRLESS SPRAYING OF DECORATIVE PROTECTIVE COATINGS & MEMBRANES USING GRACO PUMPS

USE

Improved application rates when applying Flexcrete's decorative protective coatings and membranes.

PUMPS



ULTRA MAX II 490 / 495



ULTRA MAX II 1095 STANDARD



GMAX II 5900 STANDARD

ACCESSORIES



Airless Hose
1/4" (6.4mm) x 7.5m (25 ft)
1/4" (6.4mm) x 15m (50 ft).

Graco Blue Max II



Graco Contractor airless spray gun.



Graco XTR 5/7 airless spray gun.



Graco XHD RAC SwitchTip and Guard.

TIP SIZE

PRODUCT	TIP SIZE		
MONODEX ULTRA	XHD 511-519		
MONODEX SMOOTH	XHD 513-523		
MONODEX CLEAR	XHD 513-519		
MONODEX UVC	XHD 515-523		
BIODEX HB	XHD 517-523		
BIODEX SHEEN	XHD 511-519		
ROOFDEX HB	XHD 517-523		
CURE-SEAL WB	XHD 511-519		

SETTINGS

	ULTRA MAX II 490	ULTRA MAX II 495	ULTRA MAX II 1095 STANDARD	GMAX II 5900 STANDARD
Maximum psi (bar)	3300 (227)	3300 (227)	3300 (227)	3300 (230)
Maximum gpm (lpm)	0.54 (2.0)	0.60 (3.0)	1.20 (4.5)	1.6 (6.0)
Weight lb (kg)	34 (15)	34 (15)	120 (55)	138 (62.7)

Typical pressure setting's for the above spray pumps: 1500-3000 psi. To optimise spray pattern and finish, adjust pressure accordingly.

CLEANING

Clean with water immediately after use.

PPE







Gloves

TOP TIPS

- 1. Prior to starting works, a trial application is recommended to optimise pressure settings, tip size and finish.
- 2. Prolong pump pressure seal life by installing PTFE seals.
- 3. Ensure the wet cup does not dry out and regularly top up with Graco TSL (Throat Seal Liquid).
- 4. Ensure gun, spray line and pump are clean, to avoid blockages.
- 5. Lubricate line and spray gun with water before attaching the tip and spraying.
- 6. Trigger gun to test spray pattern and adjust pressure to eliminate heavy edges.
- 7. Hold gun a minimum of 12" (300mm) from substrate, spray back and forth overlapping strokes by 50%.
- 8. Clean tips and tip guard regularly during spraying.
- 9. Regularly check tips for wear.
- 10. Ensure a sufficient supply of spare tips, spray hoses and spray guns are available.
- 11. Ensure a regular maintenance programme for the pump is in place and that worn components are replaced as required.
- 12. Always engage the safety catch on the gun during stoppages to avoid accidental triggering.
- 13. Remove guard and tip from gun, clean thoroughly if prolonged stoppages occur.
- 14. Spray water under pressure to clean lines and pressure pot. Continue until water runs clear.



Flexcrete Technologies Limited

Tomlinson Road

Leyland

Lancashire

PR25 2DY

United Kingdom

Tel: +44 (0) 845 260 7005

Fax: +44 (0) 845 260 7006

Email: info@flexcrete.com





FM 41091 EMS 597350 OHS 597351